



12VDC 18 OUTPUT SWITCH MODE CCTV POWER SUPPLY

Connection Diagram:


Switch Mode Power Supply



Test & Measurement:



To determine the current (A) draw of a camera remove the jumper link, set your meter to — A/ Amps DC, and with the camera connected measure the current across the ON and COMMON terminals.



LED Fuse Status Indicator
LED ON = Fuse OK
LED OFF = Fuse Fault

Specifications:

Input Voltage: AC 100~120V
AC 220~240V

★ For Indoor Use Only